

VAN STEENBURGH ENGINEERING LABORATORIES
 RECLAIMER PARTS - PRICE LIST

October 1, 2008

JV/BV	LV	CV	RV	VS	Description
02-023	02-023	02-023	02-023		Adapters R134a 1/2 ACME
16-002					Air Condenser
	16-003				Air Condenser
		16-007			Air Condenser
16-011					Air Condenser 4 Row
			16-019		Air Condenser
09-119	09-119	09-119			Air Out/Compressor Momentary Switch
		09-138			Capacitor CV, Run
	09-079	09-079			Capacitor Assembly for 220/1/50 15-076
			15-107		Cart
24-001					Casters - brakes
24-002					Casters - no brakes
	24-003				Casters - no brakes
	24-004	24-004			Casters - brakes
09-036	09-036	09-036			Chiller Toggle Switch
			15-116		Compressor 230/1/50
			15-117		Compressor 115/1/60
	15-075	15-075			Compressor - 115 V, 60 Hz, 1 Ph, 1 Hp (Copeland)
	15-077	15-077			Compressor - 220/240 V, 50 Hz, 1 Ph, 1 Hp (Copeland PAZ)
			15-121		Compressor 230/1/50 with shroud and fan
			15-119		Compressor 115/1/60 with shroud and fan
			13-024		Compressor only 120/1/60
	15-076	15-076			Compressor - 208/230 V, 60 Hz, 1 Ph, 1 Hp (Copeland IAV) (requires Capacitor Assembly #09-079)
15-097					Compressor 208V 60Hz 1Ph Not Avail Bristol
15-100					Compressor 220/240 V 50 Hz Not Avail Bristol
15-098					Compressor 460V 60Hz 3Ph Not Avail Bristol
15-099					Compressor 208V 60Hz 3Ph Not Avail Bristol
15-061					Compressor 208/230 V 60 Hz Not Avail Copeland
15-063					Compressor - 208/230/60/3 2Hp Copeland
15-064					Compressor - 220/240 V 50 Hz Not Avail Copeland
15-062					Compressor - 460/60/3 2Hp Copeland
15-108					Comp 208/230-1-60 Tecumseh R relay, st, run cap?
22-011	22-011	22-011			Compressor Oil Sight Glass (Units built after 10/02)
22-002	22-002	22-002			Compressor Oil Sight Glass (Units prior to 10/02)

JV/BV	LV	CV	RV	VS	
35-013	35-013	35-013	35-013	35-013	Compressor Oil POE 1/2 Gallon
35-014	35-014	35-014	35-014	35-014	Compressor Oil POE 1 Gallon
09-036				09-036	Compressor On/Off Toggle Switch
	09-036	09-036			Compressor On/Off Toggle Switch
			09-168		Compressor/Vapor Switch
09-034					Contactor (Compressor)
09-035	09-035	09-035		09-035	Crankcase Heater - 230V (CV, LV 230v)
	09-136	09-136		09-136	Crankcase Heater - 115V
			16-017		Cylinder 30 lb. with float and air purge
			16-022		Cylinder, Recovery 125 pound, w/o float
			16-020		Cylinder 30 lb. without float
21-001	21-001				Drier/Filter C-303 (Units prior to 01/94)
26-001	26-001	26-001			Drier/Filter Tower (24") (Units built after 01/94)
			26-002		Drier/Filter Tower (18") for RV
				21-010	Drier/Filter C-053
12-015					Expansion Valve - R12 NIF-1
12-017					Expansion Valve - R22 NIV-1
12-014					Expansion Valve - R500 NID-1
12-016					Expansion Valve - R502 NIR-1
	12-019	12-019			Expansion Valve - R12 NIF-1/4
	12-021	12-021			Expansion Valve - R22n NIV-1/4
	12-018	12-018			Expansion Valve - R500 NID-1/4
	12-020	12-020			Expansion Valve - R502 NIR-1/4
				09-181	Equalizer Push Button
18-003	18-003	18-003	18-006		Fan Blade
			09-166		Fan Motor 230v
			09-165		Fan Motor 115v
09-053	09-053	09-053			Fan Motor - 230V (CV, LV 230v)
	09-100	09-100			Fan Motor - 115V
09-067					Fan Motor - 460V
17-001					Fan Pressure Control
		21-002			Filter Core (Units prior to 1/94)
		21-003			Filter Shell (Units prior to 1/94)
22-003	22-003	22-003			Float Switch Assembly (WATSCO) (Non-UL) Not Avail
22-004	22-004	22-004			Float Switch Assembly (GEM) (UL)
15-112	15-112	15-112			Float Assembly, Complete with float & housing
09-109	09-109	09-109			Float Switch Reed (RLM-S) WH Not Avail
09-113	09-113	09-113			Full Light
	09-112	09-112			Fuse 20 Amp
09-111					Fuse 1 Amp
09-110	09-110	09-110			Fuse Holder

JV/BV	LV	CV	RV	VS	
10-002					Head Pressure Gauge
	10-004	10-004	10-004	10-004	Head Pressure Gauge
16-001					Heat Exchanger
			17-004		High Pressure Control
17-003	17-003	17-003			High Pressure Control
				17-005	High Pressure Contro Manual reset
12-008	12-008	12-008	12-008		High Pressure Relief Valve
12-053	12-053	12-053	12-053		Hoses 1/4"
09-155	09-155	09-155		09-155	Hour Meter 115v
	09-187	09-187		09-187	Hour Meter 230 volt (CV, LV 230 volt model)
12-004	12-004	12-004			Inlet/Outlet 1/4" flare Bulkhead
		12-039	12-039	12-039	Inlet Regulating Valve
09-002					Liquid Injection Relay
12-034	12-034	12-034	12-034		Liquid Injection Valve
17-002	17-002	17-002	17-002		Low Pressure Control
32-031	32-032	32-033	32-040		Manual Operating
22-007	22-007	22-007	22-007		Moisture Indicator (Tower) Sight Glass only
15-133	15-133	15-134	15-134		Moisture Indicator Assembly (Tower)
12-005	12-005	12-005			Oil Access Valve
16-008	16-008	16-008			Oil Separator
15-128					Oil Separator, 2 stage
				16-023	Oil Separator
				09-182	Power Light, Green
				09-189	Power Light, Red
			09-118		Reclaim/Pump Out Switch
	12-067	12-067			Refrigerant In/Out 90 Degree Valve (Units built after 02/03)
		12-035	12-035		Refrigerant In/Out Ball Valve 1/8" (CV's prior to 02/03)
12-042	12-042	12-042			Refrigerant Ball Valve (3/8") Filters
	12-023				Refrigerant In/Out Hand Valve 1/4" Flare (LV's prior to 02/03)
12-024	SS30	SS60	SS 90	only	Refrigerant In/Out Hand Valve 1/4" Solder
09-036					Refrigerant In/Out Toggle Switch
09-058	09-058	09-058			Refrigerant Selector Knob
09-031					Refrigerant Selector Switch Assembly
	09-052	09-052			Refrigerant Selector Switch Assembly
22-001	22-001	22-001			Refrigerant Sight Glass Inlet/Outlet Sporlan SA13S
09-146					Relay (for Bristol - 60 Hz Not Avail)
09-149					Relay (for Bristol - 50 Hz)
09-175					Relay Tecumseh 208/230-1-60 (goes with 15/108)
09-148					Run Capacitor for Bristol Not Avail
09-151					Run Capacito (for Bristol - 50 Hz)
09-176					Run Capacitor Tecumseh 208/230-1-60 (goes with 15/108)

JV/BV	LV	CV	RV	VS	
12-009	12-009	12-009	12-009	12-009	Solenoid Valve does not include coil
12-032	12-032	12-032			Solenoid, Air Out (XVF) with coil
12-010	12-010	12-010	12-010	12-010	Solenoid Coil - 120V
	12-026	12-026	12-026	12-026	Solenoid Coil - 230V
09-147					Start Capacitor (for Bristol - 60 Hz) Not Avail
09-150					Start Capacitor (for Bristol - 50 Hz)
09-178					Start Capacitor Tecumseh 208/230-1-60 (goes with 15/108)
10-001					Suction Pressure Gauge
	10-003	10-003	12-003	10-003	Suction Pressure Gauge
			12-061		Three Way Valve
09-065					Transformer
10-006	10-006	10-006			Temperature Gauge
15-111					Tube Kit for Tecumseh compressors (Replacing Bristol)
09-037					Vapor Oil/Out Toggle Switch
	09-036	09-036			Vapor Toggle Switch
		24-006	24-026	24-006	Wheel - 10" Pneumatic (each)
	24-005	SS30, SS60, SS90 only			Wheel - 10" Hard Rubber SS30, 60, 90

PRICES SUBJECT TO CHANGE WITHOUT PRIOR NOTICE